

## SMX-200 PIN Define

PIN No.	RS-232	RS-422 (5-wire)	RS-422 (9-wire)	RS-485 (3-wire)
1	GND_ EARTH	GND_ EARTH	GND_ EARTH	GND_ EARTH
2	GND	GND	GND	GND
3	RI	—	CTS-	RI
4	DTR	RXD-	RXD-	—
5	CTS	—	CTS+	—
6	TXD	RXD+	RXD+	—
7	RTS	—	RTS+	—
8	RXD	TXD+	TXD+	DATA+
9	DSR	—	RTS-	—
10	DCD	TXD-	TXD-	DATA-